

Helpful Construction Hints

To prevent cracking in Pro Cyc joints:

- Grind edges before bolting modules together.
 - Pro Cyc recommends the use of a palm sander with 30-grit sandpaper.
- Bolt as close to face of cyc modules as possible. (Applies to System 1.5 and System 5.)
- Very rough grind to surface where joint mud goes.
 - Pro Cyc recommends the use of a palm sander with 30-grit sandpaper.
- Use bonding agent in joint area – this helps mud bond to cyc modules.
 - Pro Cyc recommends a light spray/mist of 3M Super 77 Spray Adhesive in the joint area.
- Use Durabond® 90-Minute Sheetrock Setting-Type Joint Compound for the first two coats of mud.
 - **Do not substitute other products for Durabond® 90-Minute Sheetrock Setting-Type Joint Compound.**
 - **Do not use “Easy Sand” or “Light” varieties.**
 - Let dry up to 24 hours (in high humidity) between each coat. When it is dry it will turn white. (This could be as little as just a couple of hours in very low humidity.)
- The top coat (third coat) of mud, use topping mud or regular wallboard compound.
 - Pro Cyc recommends Beadex® All-Purpose Joint Compound.
- At the floor, sweep dry mortar mix behind the floor modules and then mist the backside for hardening.
 - This step reinforces the leading edge of the floor modules.

Primer & Paint Recommendations:

- **Primer**
 - Apply two coats of high-quality, interior-latex, white, stain-blocking primer before painting.
 - Pro Cyc recommends Kilz® Premium Primer.
- **White Paint**
 - Pro Cyc recommends any good quality latex flat interior white paint.
- **Chroma Key Paint**
- Pro Cyc recommends using Digital Green® paint offered by Composite Components as the best complement to our Pro Matte™ flooring. Other chroma key paints may vary significantly in color or shading from Pro Matte™ – failing to produce the intended result. Digital Green® is a trademark of Composite Components Company. Contact:
Composite Components Company
134 N. Avenue 61, Unit 103
Los Angeles, CA 90042
(323) 257-1163
(323) 257-0604 fax
www.digitalgreenscreen.com
- Recommended – three coats of paint using a 5/8” to 3/4” nap roller.
- Use a 4” roller with 5/8” to 3/4” nap to apply paint to Pro Cyc’s corner parts.
- Make sure to keep extra paint on hand for touchups.
- (Composite Components also offers Digital Blue® paint.)