

Pro Cyc – Helpful Construction Hints

To prevent cracking in Pro Cyc joints...

- Grind flanges and surface where joint mud goes before bolting modules together. Use a palm sander with 60-grit sandpaper. (Same grit used to prep surface of modules before priming and painting.)
- Use Durabond® 90-Minute Sheetrock® Setting Type Joint Compound for the first two coats of mud.
 - **Do not substitute other products for Durabond® 90-Minute Sheetrock® Setting-Type Joint Compound.**
 - **Do not use “Easy Sand” or “Light” varieties.**
 - Let dry up to 24 hours (in high humidity) between each coat. When it is dry it will turn white. (This could be as little as just a couple of hours in very low humidity.)
- The top coat (third coat) of mud, use topping mud or regular wallboard compound.
 - Pro Cyc sells Beadex® All-Purpose Joint Compound.
- Sweep or scrape dry mortar mix behind the floor modules where they taper to the floor. After packing to a height of approximately 2-1/2” spray-mist the backside for hardening.
 - This step reinforces the leading edge of the floor modules.

Pro Cyc’s Virtual Green® Chroma Key Paint & Grey Bonding Primer System

- Other chroma key paints may vary significantly in color or shading from Pro Cyc’s Pro Matte® Flooring – failing to produce the intended result.
- **Pro Cyc’s Grey Bonding Primer**
 - One generous coat.
 - Apply using a 9” roller with 3/4” nap.
 - Use a 3” or 4” roller with 3/4” nap to prime Pro Cyc’s corner parts.
- **Pro Cyc’s Virtual Green® Chroma Key Paint**
 - Minimum two generous coats (possibly three coats).
 - Use a 9” roller with a 3/4” nap.
 - Use a 3” or 4” roller with 3/4” nap to paint Pro Cyc’s corner parts.
 - Make sure to keep extra paint on hand for touchups.

When Painting White or Other Color:

Primer –

- **Pro Cyc’s Grey Bonding Primer**
 - One generous coat.
 - Apply using a 9” roller with 3/4” nap.
 - Use a 3” or 4” roller with 3/4” nap to prime Pro Cyc’s corner parts.

Paint –

- Use any high quality, flat (non-glossy) interior latex paint.
 - Recommended – three generous coats of paint using a 3/4” nap roller.
 - Use a 3” or 4” roller with 3/4” nap to paint Pro Cyc’s corner parts.
 - Make sure to keep extra paint on hand for touchups.