

APPLICATION INSTRUCTIONS GREY BONDING PRIMER & VIRTUAL GREEN® CHROMA KEY PAINT

Congratulations on your decision to use the world's most advanced chroma key paint and primer system.

IF YOU INTEND TO USE YOUR CYC AS A GREEN SCREEN – AND YOU INTEND TO USE PRO CYC'S PRO MATTE® FLOORING – YOU MUST USE PRO CYC'S GREY BONDING PRIMER AND PRO CYC'S VIRTUAL GREEN® CHROMA KEY PAINT TO GET THE BEST POSSIBLE COLOR MATCH.

PRO CYC'S VIRTUAL GREEN® PAINT IS TRANSLUSCENT AND PRO CYC'S GREY BONDING PRIMER IS SPECIFICALLY TINTED TO INFLUENCE THE FINAL COLOR OF THE VIRTUAL GREEN® PAINT.

PRO CYC'S VIRTUAL GREEN® PAINT IS SPECIALLY DESIGNED FOR USE IN TELEVISION AND MOTION PICTURE VIRTUAL REALITY PRODUCTION STUDIOS. THIS PAINT IS INTENTIONALLY THICK AND SHOULD NOT BE THINNED.

Please review your shipment to make sure all items listed on your quote match up to the items shipped. If there is a discrepancy, please call us right away to get the problem resolved.

1. Tools

You will need the following tools & supplies:

- Clean shop towels or cloths
- Stir stick (a heavy-duty drill with a paint stirring attachment is helpful, not required)
- Paint tray with disposable liners
- 9" paint roller

- 9" paint roller covers with 3/8" nap
- 9" paint roller covers with 3/4" nap

If you are painting a cyclorama with a corner:

- 3" or 4" paint roller
- 3" or 4" paint roller cover with 3/8" nap
- 3" or 4" paint roller cover with 3/4" nap

2. Sanding & Cleaning the Cyc

If you are installing a Pro Cyc cyclorama system be sure to sand the entire surface of your cyc (including the sheetrock if your system is built in) with 60-grit sandpaper – per Pro Cyc's installation instructions. This will provide for better primer adhesion.

After sanding, clean your cyc with a damp cloth. Dust from the sanding process can interfere with primer adhesion. This is also a good time to clean the sanding dust from your studio.

3. Prime the Cyclorama

After wiping the entire cyc with a clean damp cloth – including the sheetrock wall (if applicable) – it is now ready to be primed.

STIR THE GREY BONDING PRIMER THOROUGHLY.

Apply one heavy coat of Pro Cyc Grey Bonding Primer using a 3/8" nap roller. Use a 3" or 4" wide roller in the base of any corners. This will help prevent lines and streaks caused by larger rollers.

One generous coat of Pro Cyc's Grey Bonding Primer should be all that is needed to make sure no shadows appear through at the joints.

4. Paint the Cyclorama

ALLOW THE GREY BONDING PRIMER TO DRY COMPLETELY BEFORE APPLYING PAINT.

STIR THE VIRTUAL GREEN® CHROMA KEY PAINT THOROUGHLY.

Apply a generous first coat of Pro Cyc's Virtual Green® Paint using a 3/8" nap roller cover. Use a 3" or 4" wide roller in the base of any corners. This will help prevent lines and streaks caused by larger rollers.

WAIT FOR EACH COAT OF PAINT TO DRY COMPLETELY BEFORE APPLYING THE NEXT COAT.

Apply a generous second coat of Pro Cyc's Virtual Green® Paint using a 3/4" nap roller cover. Use a 3" or 4" wide roller in the base of any corners. This will help prevent lines and streaks caused by larger rollers.

In some cases, apply a generous third coat of Pro Cyc's Virtual Green® Paint using a 3/4" nap roller cover. Use a 3" or 4" wide roller in the base of any corners. This will help prevent lines and streaks caused by larger rollers.

THE 3/4" NAP ROLLER COVERS USED ON THE FINAL COAT(S) OF PAINT WILL LEAVE AN "ORANGE PEEL" TEXTURE. THIS TEXTURE IS INTENTIONAL – IT HELPS TO TRAP LIGHT INSTEAD OF REFLECTING IT BACK TO THE CAMERA.

Repaint as often as necessary over the life of the cyc.

5. Questions?

Please give us a call at: (503) 723-7448.

You can also email us at: info@procy.com

QR Code for Instructional Video:

