

ASSEMBLY INSTRUCTIONS

SYSTEM SUPER 2.5 EZ

Congratulations on your decision to use the world’s most advanced and user-friendly cyclorama system. We have taken a great deal of care to create and ship your cyc, so please take a minute to visually inspect the packaging before you sign the receipt to accept the shipment. Are there any signs of damage, including puncture holes or signs of crushing?

If there is visible damage, insist that the damage be noted on your bill of lading and that either the delivery person or a representative from the delivery company be present when you open the packaging. Pro Cyc will not honor claims for damage if the bill of lading has been signed without noting and alerting the carrier of damage. The only exception is if the damage is internal. In that case, keep the packaging so it can be inspected.

Review your Pro Cyc shipment to make sure all items listed on your quote match up to the items shipped. If there is a discrepancy, please call us right away to get the problem resolved.

Let’s Assemble Your Cyc:

1. Tools

You will need the following tools & supplies for assembly of the cyc:

- Circular saw
- Stud finder
- Sockets and drivers; 7/16”
- Clamps or vise grips
- Chalk line
- 24” long level
- Carpenter’s square
- 1/8” drill bit
- Drift pin to align 9/32” holes
- Drill motor
- Roto-hammer with 5/32” masonry drill bits (only if

attaching cyc to concrete wall or floor)

- Canned air
- Framing hammer
- Screwdriver (Phillips & flat)
- Palm sander w/60-grit sandpaper
- Clean shop towels or cloths
- 4” minimum width horizontal furring strips or plywood – enough to match up to total length of floor cove cyc-to-wall contact area
- Vertical furring strips or plywood - same width as the distance on center between studs in your wall. The height of these strips needs to be 24 inches less than the overall height of your finished cyc. You should have two furring strips or pieces of plywood this size for every corner in your cyc. (L-shaped cycs have one corner; U-shaped cycs have two corners.)
- All furring strips or plywood should be the same thickness as the sheetrock in your wall
- Sheetrock knife
- Drywall tools
- Pro Cyc’s Grey Bonding Primer
- Paint
- Paint supplies
- ABS plastic glue or cement (Available in plumbing supply stores. This adhesive is only required if you need to trim your cyc to fit your studio.)

2. Sanding the Modules

Sand the entire surface of each cyc module with 60-grit sandpaper. This will provide for better paint adhesion.

Be sure to also sand the outside edges and the side flanges with 60-grit sand paper. This will provide for better joint compound adhesion and help create a non-slip surface when bolting the modules together.

Sanding before assembly will help make sure outside edges coming in contact with the joint compound are not missed.

After sanding, clean each module with a damp cloth. Dust from the sanding process can interfere with paint and joint compound adhesion. This is also a good time to clean the sanding dust from your studio.

3. Framing

Begin in the corner of the wall where you will remove two strips of sheetrock and replace them with furring strips or plywood so you have a solid surface to which you attach your Pro Cyc corner modules.

When installing a Super 2.5 EZ corner, you will need to assemble the corner modules prior to measuring for your wood furring strips. Bolt together Part #2.5A-EZ and #2.5V-EZ using 1/4”-20 x 1” Bolts, nuts and washers. Make sure there are two washers used for each hole. Before tightening the bolts completely, make sure the faces of these corner modules are aligned perfectly.

When the corner assembly is complete, slide it into the corner of the room and mark where the #2.5V-EZ coves meet the wall with vertical lines. Make sure that both sides are equidistant from the corner and are approximately 40 inches from the corner.

Pull the corner assembly away from the walls, so you have room to work. Next, using a stud finder, locate the studs in your existing wall. From the lines marking the

vertical edges of your corner section, locate the closest stud inside each line and outside each line. Remove the sheetrock between the two studs on the left and the two studs on the right. Begin this process by cutting the sheetrock with a knife or circular saw 24 inches above the floor and up to the planned height of the top vertical module. (BE CAREFUL NOT TO CUT COMPLETELY THROUGH THE SHEETROCK WITH A CIRCULAR SAW. IF THE STUDS ARE METAL THE DAMAGE CAN BE STRUCTURAL. COMPLETE THE CUT WITH A SHEETROCK KNIFE.) Make the cuts through the sheetrock, along the center of each stud. Remove the sheetrock between the studs and replace it with plywood or furring strips that are the same thickness as the sheetrock you removed.

Now you need to remove horizontal strips of sheetrock along the top of the floor coves' length and width of your cyc and replace them with plywood or furring strips so you have a solid surface to which you attach the top of your floor-cove modules.

Begin in the corner and measure out at least as long and wide as your cyc. Terminate each strip into the stud that is equal to or longer/wider than your cove unit. Each strip should butt up to the outside edge of the furred out vertical strips you have in place. Measure up from the floor 24 inches and mark the wall at either end of your cyc. Next, mark the wall 4 inches above your first mark. Use a chalk line to mark the area to be removed. Using a sheetrock knife or a circular saw, remove the sheetrock between your two lines and replace it with plywood or furring strips that are the same thickness as the sheetrock wall. (AGAIN, BE CAREFUL NOT TO CUT COMPLETELY THROUGH THE

SHEETROCK WITH A CIRCULAR SAW. IF THE STUDS ARE METAL THE DAMAGE CAN BE STRUCTURAL. COMPLETE THE CUT WITH A SHEETROCK KNIFE.)

NOTE: Adding an additional layer of sheetrock (on top of your existing sheetrock with furring strips) will help with soundproofing and it will also render an improved fire rating. If you choose to install a second layer of sheetrock make sure to use drywall screws that are long enough to reach the furring strips when you attach the Pro Cyc modules to the wall.

4. Trimming Your Cyc to Fit Your Studio (See Figure L)

Snap a chalk line at the desired length and use a circular saw to cut the module to the size.

Next, cut the remaining part one inch from the flanged end so you can re-attach the flange. Clean off any burrs or debris from the plastic before using ABS adhesive or cement (available in plumbing supply stores) to fasten the flanged end behind (under) the cut-to-length module. Clamp the parts together until the glue is dry.

You will need to trim the floor and/or wall side of the flange back to the point where it will allow you to align the face of the trimmed module with the face of the adjoining module.

5. Assembly

With your plywood or furring strips in place, begin to assemble your Pro Cyc modules. Before assembly, make sure that the flanges on the modules do not prevent the cyc from fitting flush to the floor or wall. If a flange holds a cove end off the floor or wall, simply grind down the flange in that area. Assemble your cyc away from the walls so you have adequate space to work.

Begin by standing a #2.5B-EZ module on its flanged side. Next, place a second #2.5B-EZ on top of the first one and align the holes with an alignment tool such as a drift pin, or even a bolt. LOOSELY bolt the two parts together using a 1/4"-20 x 1" bolt, washer, washer and nut. When all of the holes are loosely fitted, tighten the bolts one by one, making certain that the face of the coves remain flush. Repeat this process with all #2.5B-EZ cove pairs that form each wall of the cyc.

Attach any remaining #2.5V-EZ vertical cove modules above the corner module(s). Install the 1/4"-20 x 1" bolts, nuts and washers using two washers for each bolt. Before final tightening, use the straight edge to make sure the modules are flush on the face. Repeat this procedure for each corner module.

Next, use as many people as necessary to fasten one pair of bolted-together #2.5B-EZ floor cove modules to the corner group assembly. Bolt the pair to the corner group making certain that the faces remain flush when tightening the bolts. This should be done on both sides of the corner assembly; and both sides of all corner assemblies if the cyc has more than one corner.

6. Attach the Cyc Corner(s) to the Wall

After the first pairs of #2.5B-EZ floor modules have been attached to the corner group(s) – and you have checked to make sure the modules are all flush on the face – push the cyc unit into place in the corner and along the wall. When the entire unit is in place, continue to shift the cyc back and forth until all areas seem to be aligned correctly against the wall and floor.

Use a level and snap chalk lines along the perimeter of the cyc making sure it is aligned perfectly

vertical in the corner and perfectly horizontal as it progresses along the floor. The horizontal chalk lines should be 26-1/2" off the floor. These chalk lines will be used for reference as more modules are added to the cyc.

Next, attach the corner modules to the wall. Make sure the modules remain perfectly vertical and do not "drift" left or right as you move up the corner and proceed to the top of the corner-cove assembly. Use a 1/8-inch drill bit to drill through the holes in the modules and into your plywood or furring strip. Work your way up the corner and attach the cyc to the wall with 1-1/4" Phillips drywall screws.

After attaching the corner and vertical modules, install 1-1/4" Phillips drywall screws in the first five holes along the top of the #2.5B-EZ floor coves that are closest to the corner assembly. Make sure the modules remain perfectly horizontal and do not "drift" up or down as you move from the corner assembly.

It is now time to attach the next pair of #2.5B-EZ floor coves. Gently pull the first pair of floor coves just far enough away from the wall to allow access for bolting the flanges to the next pair. Make sure the modules are all flush on the face before tightening the 1/4"-20 x 1" bolts, washers and nuts.

Continue to install 1-1/4" Phillips drywall screws along the top of the #2.5B-EZ floor coves and repeat the above steps until all floor coves are attached to the wall(s).

7. Fastening the Bottom Edge to the Floor

After the top and sides of the corner modules and the top of your floor coves have been attached, it is time to position and fasten the bottom of your cyc to the floor. Using both hands, grab the cyc from underneath, pull it

forward, and then let it fall gently into place.

To secure the cyc to the floor, begin in the corner and work toward each end of the cyc.

Drill through the cove modules into the floor. If you are attaching to concrete, you should use a roto-hammer and 5/32" carbide masonry drill bits to install 3/16" x 1-1/4" flat-head Phillips concrete screws. Drill the holes a minimum of 1-1/2" deep. If you are fastening into a wood floor, you should use 1/8" drill bits to install 1-1/4" Phillips drywall screws.

Before installing the screws blow out each hole with canned or compressed air.

8. Finish the Joints and the Tapered Edge at the Floor

The tapered edge at the floor may be done either simultaneously with the joint mudding or subsequent to the joints. The completed feathered edge at the cyc-to-studio-floor transition will typically extend 4" to 6" in front of the front edge of the cyc modules. This feathered edge completes the radius of the cove module.

Make sure that the surfaces of all modules are properly sanded (see Step 2) and wiped down in order to remove sanding dust. Use a self-adhesive fiberglass mesh tape on the joints that transition from the coves to the wall and from the coves to the floor. Be sure to press the tape into the crack with your finger as you apply the tape.

DO NOT USE FIBERGLASS MESH TAPE AT THE JOINTS BETWEEN MODULES. THESE AREAS ARE NOT RECESSED ON THE MODULES TO ACCOMMODATE TAPE.

Use a 90-minute drywall mud such as Durabond 90 Setting Type Joint Compound to mud the joints.

DO NOT USE EASY SAND JOINT COMPOUNDS, AS THEY HAVE POOR TACKING QUALITIES.

ALLOW PLENTY OF TIME FOR THE MUD TO COMPLETELY DRY BEFORE APPLYING SUBSEQUENT COATS. This is because moisture can only escape through the face of the joint.

Wet sand or dry sand the joints and re-coat with the 90-minute mud. Wet or dry sand again. For the third and final coat, use a regular box or bucket mud, such as Beadex All Purpose Joint compound, to float out the seams. Sand and wipe down the cyc one last time before painting.

Do not cap off the ends or the top of the corner on your cyc. It is important to allow the free flow of air behind the cyc. Temperature differences between the front and the back of the cyc can create uneven expansion and contraction. This can cause drywall mud to crack.

9. Prime & Paint the Cyclorama

Wipe the entire cyc with a clean damp cloth – including the sheetrock wall. It is now ready to be primed. Apply one generous coat of Pro Cyc's Grey Bonding Primer using a 9" roller with a 3/8" nap. Use a 3" roller in the corner area.

Paint your cyc with either a roller or an airless spray gun. See Pro Cyc's Helpful Construction Hints (available for download on our website) for useful tips on painting your cyc with a roller.

Repaint as often as necessary over the life of the cyc. Clean between each coat. Wearing surgical booties and/or putting plastic on the floor coves during rehearsal or studio prep will prolong the time between new coats of paint.

10. Questions?

Please give us a call at:
(503) 723-7448. You can also
email us at:

info@procy.com

Instructions, schematics, helpful
construction hints and other


recommendations can be found on
our website:

www.procy.com

Scan this QR Code for a link to an installation video for System Super 2.5EZ. Please note – if you find any differences between the video and the written installation instructions always follow the written instructions.



System Super 2.5 EZ






Figure L

